



[www.customcargrills.com](http://www.customcargrills.com)  
[info@customcargrills.com](mailto:info@customcargrills.com)

customcargrills.com LLC  
PO Box 90004  
Grand Rapids, MI 49509  
(616) 889-2985

Year: 1984-1990  
Make: Chevy  
Model: Corvette

## INSTALLATION INSTRUCTIONS



**What's in the Box:** (2) Mesh Grill Inserts.

**Tool List:** Low Adhesion Masking Tape, 3M Foam Tape, Small Screws (optional)

### Mesh Installation:

1. Place the mesh insert in the grill area. Make sure the fit is correct. It may be a little tight at first but this is normal.
2. When you are satisfied with the placement, use some low adhesion masking tape and outline the area where the grill is.
3. Remove the grill insert.
4. Using the low adhesion tape as a guide, outline the grill area with the 3M Red-Back tape.
5. Remove the low adhesion tape.
6. Remove the red back from the foam tape.
7. Push the grill insert back in until it contacts the foam tape.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to [info@customcargrills.com](mailto:info@customcargrills.com) .