



[www.customcargrills.com](http://www.customcargrills.com)  
[info@customcargrills.com](mailto:info@customcargrills.com)

customcargrills.com LLC  
PO Box 90004  
Grand Rapids, MI 49509  
(616) 889-2985

Year: 2003-2005  
Make: Dodge  
Model: Neon SRT-4

## INSTALLATION INSTRUCTIONS



**What's in the Box:** (2) Mesh Grill Inserts.

**Tool List:** Ratchet, 5/16" Socket, 10mm Socket, Ratchet Extension, Phillips Screwdriver, Torx T25.

### Grill Mesh Installation:

1. Remove 5 screws under the front bumper lip (5/16<sup>th</sup>)
2. Remove 3 screws holding the top of the front bumper closest to you (5/16<sup>th</sup>)
3. Remove headlight assembly (two 5/16<sup>th</sup> screws on each light). Unplug headlight and turn signal bulbs. To remove lights completely, it is necessary to pull on the front fascia to allow room for the headlight to be removed. Don't worry, the piece is very flexible.
4. Unplug fog light bulbs.
5. Unplug corner light bulbs.
6. Remove bolts from inside of fender wall which connect front bumper to quarter panels. There are 3 bolts on each side, 10mm.
7. Remove 2 bolts from each side on outside of fender in wheel well, Torx T25. It's easier to gain access if the wheel is turned.
8. Remove front bumper.
9. To change grills, there are 6 Phillips screws on each grill. Remove all bolts and replace old grill with new one.
10. Replace all 6 screws. When doing this, it's advisable to slowly tighten each bolt to allow for the metal to form to the fascia.
11. The upper pieces can be installed one of two ways. For a deep install, trim the mesh down to size and affix it to the back of the black plastic piece that goes inward toward the engine bay. For a flush mount install, remove the black plastic trim piece and affix the mesh directly to the back of the bumper.
12. Replace front bumper on car. Be sure that the black piece of the wheel well liner is on the inside of the nose.
13. Put the 3 bolts back on each side on the inside fender wall. When doing this, pay attention to the alignment of the nose with the body of the car.
14. Replace T25 bolts on outside of wheel well.
15. Plug in fog light and corner light bulbs.
16. Reinstall headlights and plug in headlight and turn signal bulbs.

17. Replace three screws in front of the nose.

18. Replace 5 screws under the front lip.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to [info@customcargrills.com](mailto:info@customcargrills.com) .