



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 1996-1998
Make: Pontiac
Model: Grand Am SE

INSTALLATION INSTRUCTIONS



What's in the Box: (2) Grill Mesh Pieces, (8) Ties, (1) Small Spool of Wire.



Tool List: Needle Nose Pliers, Wire Cutters.

Mesh Installation:

1. Remove the two stock front top pieces. You have to remove the bottom half of the insert first. You also must pry the bottom tabs up. This is usually easier to do from behind the insert.
2. Lay the grill insert over the stock insert as shown.



3. Take about 6-7" of the wire and bend it in a V shape and run it through two adjacent diamonds that overlay a stock horizontal bar. Ties can be used instead of the wire if desired.

4. From behind, twist the wire in spiral pattern.



5. When you can twist it much longer, and then use a pair of need nose pliers to make a snug fit with the desired tension.



6. Once tightened to the desired tension then trim off the excess. You will still want to leave about 1/8"-1/4" on there.



7. Reinstall the top inserts. Hook the inserts in at the top and then push the bottom tabs in to place. A common mistake on the install is having the inserts positioned too high.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com .