



[www.customcargrills.com](http://www.customcargrills.com)  
[info@customcargrills.com](mailto:info@customcargrills.com)

customcargrills.com LLC  
PO Box 90004  
Grand Rapids, MI 49509  
(616) 889-2985

Year: 1997-2000  
Make: Saturn  
Model: SC

## INSTALLATION INSTRUCTIONS



**What's in the Box:** (1) Grill Mesh Piece.

**Tool List:** Needle Nose Pliers, Adhesive (Automotive Goop, Permatex, or similar)

### Mesh Installation:

**Method 1:** Begin by using the two smaller of the four rectangle sections. You may need to bend them into a little “L” shape to get the tension from the back to press these forward. These pieces will go in the sides nearest the center. Insert one of these sections into the large central opening and slide it towards the outer opening. Use an adhesive to seal the grill on.

To install grill into the center opening, insert the left half of grill section behind bumper and in front of fog lights if applicable in a similar method to the install of the side pieces. The top side of the grill should be resting on the styrofoam beam that is above the fog lights, behind the bumper cover. Be sure to not sit the mesh against your paint as you feed the rest of the grill through to the right side. Once in, just center the grill and apply adhesive where need be.

To install the grill sections into the far left and right openings, you will have to reach underneath the car and place the grill on the plastic backing. Again, you may have to make them into an “L” shape and then use adhesive to seal the grill on.

**Method 2:** Same as above except for the center piece you can use 2 wire ties. These will feed through the grill and two little holes that are located on the center bottom part of the portion of the center section. They are rectangular in shape and should be a few inches apart.

**Method 3:** This involves taking your front end off for a permanent install. Remove your bumper by taking the appropriate clips and drill small little holes at your discretion to where you think they should go for attachment of the grill. Then just feed the wire ties through the bumper and then through the grill and trim. Repeat for each insert and then put back together as you took off.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to [info@customcargrills.com](mailto:info@customcargrills.com) .